

# MODEL 2216e TEMPERATURE CONTROLLER

## INSTALLATION AND OPERATION HANDBOOK

Contents	Page
Chapter 1	OPERATION ..... 1-1
Chapter 2	INSTALLATION ..... 2-1
Chapter 3	ACCESS LEVELS ..... 3-1
Chapter 4	TUNING ..... 4-1
Chapter 5	CONFIGURATION ..... 5-1
Chapter 6	USER CALIBRATION ..... 6-1
Chapter 7	ALARM CONFIGURATION ..... 7-1
Appendix A	UNDERSTANDING THE ORDERING CODE ..... A-1
Appendix B	SAFETY & EMC INFORMATION ..... B-1
	TECHNICAL SPECIFICATION ..... B-6
Appendix C	ADDRESS ..... C-1
Appendix D	VALVE POSITIONER ..... D-1
Appendix E	LOAD CURRENT MONITORING ..... E-1
Appendix F	RETRANSMISSION ..... F-1

“This product is covered by one or more of the following US Patents:  
5,484,206 and 5,793,754; Additional patents pending.

PDSIO® is a registered trademark of Eurotherm.

INSTANT ACCURACY™, SSRx Load Doctor™ and SSRx Enhanced Load Doctor™  
are trademarks of Eurotherm.”




# Chapter 1 OPERATION

	<b>PAGE</b>
<b>Front Panel Layout</b> .....	<b>1-2</b>
<b>GETTING STARTED</b> .....	<b>1-4</b>
<b>Navigation Diagram</b> .....	<b>1-10</b>
<b>Parameter Tables</b> .....	<b>1-12</b>
<b>Setting Alarm Levels</b> .....	<b>1-18</b>
<b>Diagnostic Alarms</b> .....	<b>1-19</b>



### FRONT PANEL LAYOUT



**Fig 1-1 Model 2216e front panel layout**



Button or indicator	Name	Explanation
OP1	Output 1	When lit, it indicates that heating output is on.
OP2	Output 2	When lit, it indicates that cooling output is on.
SP2	Setpoint 2	When lit, this indicates that Setpoint 2 has been selected.
REM	Remote Setpoint	When lit, this indicates that the PDSIO® remote Setpoint input has been selected. 'REM' is also used to indicate that user comms is active.
MAN	Manual light	When lit, it indicates that manual mode has been selected
RUN	Run light	When lit, it indicates that Setpoint rate limit is active.
	Page button	Press to select a new list of parameters.
	Scroll button	Press to select a new parameter in a list.
	Down button	Press to decrease a value in the lower readout.
	Up button	Press to increase a value in lower readout.

**Figure 1.3 Controller buttons and indicators**

**NOTE**



For Valve Positioning, please refer to Appendix D 'Motorised Valve Control'




## GETTING STARTED

Thank you for selecting the EUROTHERM 2216e controller. This section shows the **principle** of operation.

### VIEWING THE PROCESS VALUE and SETPOINT

**Install and wire up** the controller in accordance with Chapter 2 and switch on. Following a 3 second self-test sequence, this is the display you will see,




**Figure 1.4 The "Home Display"**

**NOTE**



The display may flash an alarm message. Refer to the Parameter Tables later in this chapter for a complete list and meaning of the messages.

### TO ADJUST THE SETPOINT




Press and hold to decrease temperature  Press and hold to increase temperature 

**Figure 1.5 The lower readout shows the setpoint**

After 2 seconds the lower readout will 'blink' indicating that the new value has been accepted. For everyday use you may not need to do anymore than this.



**VIEWING THE DISPLAY UNITS**




**Figure 1.6** Pressing or will flash the display units for 0.5 secs

**NOTE** If you get lost, pressing and together will return you to the Home display

**USE OF THE “SCROLL” BUTTON**

Pressing the scroll button will display the output power level. Continued pressing will display further parameters in the operator scroll list.



Keep pressing to return to Home display or select further parameters (if available)


**Figure 1-7** Upper readout is parameter name. Lower is value



### USE OF THE PAGE BUTTON

The “PAGE” button  accesses parameter LISTS.

Parameters are settings in the instrument which, generally, can be changed by the user to suit the process. Examples are: Alarms, Self Tune, etc. They are found under headings called **LISTS** and a full set is given later in this chapter.



**Figure 1.8** Press  to choose a parameter list

**NOTE**




The actual list headings may be longer or shorter than indicated above and you can customise this for the operator’s convenience in EDIT level, Chapter 3.



**PARAMETER LISTS**

Press  to choose a LIST - "ALARMS" is a good one. This list allows you to set the alarm trip levels. The parameters which appear in the list will vary according to the configuration of your controller.



**Figure 1.9 Choose a list. Press  to select a parameter**

**NOTE**



If, at any time, no key is pressed within 45 seconds, the display will always return to the "HOME" display.



**OPERATING MODES**

The controller can be used in two modes:


**Automatic mode** - in which the output power is automatically adjusted to hold the temperature at the required value. The controller normally operates in this mode.

**Manual mode** - in which the output is manually adjusted by the Operator. In this mode the 'MAN' light will be on. Unit must be in full access to see 'MAN'.

One other mode is available:

**Remote setpoint** - The setpoint is generated as an input signal from a master 2000 series controller. In this mode the REM light is on.

**AUTO or MANUAL SELECT**



**Figure 1.10 Auto/Manual select**



## MANUAL ADJUSTMENT OF OUTPUT POWER




Figure 1.11 The “Home Display” in manual mode

### NOTE



Manual mode is generally used for test and commissioning purposes, take care not to leave the controller in this mode since damage or personal injury could occur.

### SUMMARY

To step through list headers press the Page button  until the required header is obtained

To step through parameters within a particular list press the Scroll button  until the required parameter is obtained

**To change the value (or state)** of a parameter press the Raise button  or the Lower button 

**The remainder of this chapter** provides a complete list of all parameters available.



NAVIGATION DIAGRAM (Part A)





Figure 1.12a Navigation diagram



**NAVIGATION DIAGRAM (Part B)**



**Notes:**

1. Either the PID list or the On/Off list will be present depending upon the type of control in use.
2. The last three characters depend upon the type of alarm configured
3. Absolute setpoint limits are set in configuration, see Chapter 5.
4. VPOS only for VP. Refer to VP Appendix D.
5. Amps is Mode 2 or Mode 5 PDSIO.
6. mtr used for VP version. Refer to VP Appendix D.
7. **Beware!** Used for calibration. See chapter 6.
8. Is only available if using PDSIO® comms in the HA slot.
9. WSP is available if using ramp to setpoint.

The shaded boxes are normally hidden in Operator level. To see all the available parameters you must select Full level. See Chapter 3, *Access Levels*

**Figure 1.12b Navigation diagram**



**PARAMETER TABLES**

Name	Parameter Description	Default Value		Minimum Value	Maximum Value	Units	Customer Setting
		UK	USA				

Home List							
Home	Measured Value and Setpoint(SP)	SP=25°C	SP=75°F			as display	
<i>vPoS</i>	Valve positioner output power			0.0	100.0	% of mtr	
<i>OP</i>	% Output Level			- 10.0	10.0	%	
<i>wSP</i>	Working setpoint					as display	
<i>SP</i>	Setpoint			-999	9999	as display	
<i>AmPS</i>	Heater current (PDSIO modes 2)			0	100	Amps	
<i>m-R</i>	Auto/manual select	<i>Auto</i>	<i>Auto</i>				
<i>di SP</i>	Configure lower readout of home display	<i>Std</i>	<i>Std</i>				None, StD, AmPS, OP, stat, vPoS
<i>ci d</i>	Customer ID	0	0	0	9999		

Additional parameters may appear in the Home display if the 'promote' feature has been used (see *Edit Level*, Chapter 3).



Name	Parameter Description	Default Value		Minimum Value	Maximum Value	Units	Customer Setting
		UK	USA				

<b>RL</b>	<b>Alarm List</b>						
1---	Alarm 1 set point value	0	0			as display	
2---	Alarm 2 set point value	0	0			as display	
3---	Alarm 3 set point value	0	0			as display	
4---	Alarm 4 set point value	0	0			as display	
<i>In place of dashes, the last three characters indicate the alarm type, as follows:</i>							
-FSH	Full Scale High alarm			-999	9999	as display	
-FSL	Full Scale Low alarm			-999	9999	as display	
-dE <sub>u</sub>	Deviation band alarm			0	9999	as display	
-dH <sub>i</sub>	Deviation High alarm			0	9999	as display	
-dL <sub>o</sub>	Deviation Low alarm			0	9999	as display	
-L <sub>cr</sub>	Low current alarm			0	100	Amps	
-H <sub>cr</sub>	High current alarm			0	100	Amps	
HYS <sub>t</sub>	Hysteresis			0	9999	as display	
L <sub>bt</sub>	Loop break time	OFF	OFF	0	9999	secs	



Name	Parameter Description	Default Value		Minimum	Maximum	Units	Customer Settings
		UK	USA	Value	Value		

<i>Autune</i>	<b>Autotune List</b>						
<i>tunE</i>	Self tune enable	OFF	OFF	OFF	on		
<i>Adc</i>	Automatic droop compensation (Manual Reset) enable (only present if <i>t<sub>i</sub></i> is set to OFF)	mAn	mAn	mAn	CALL		

<i>Pid</i>	<b>PID List</b>						
<i>Pb</i>	Proportional band	20.0		0.0	9999	as display	
<i>t<sub>i</sub></i>	Integral time	360		OFF	9999	seconds	
<i>t<sub>d</sub></i>	Derivative time	60		OFF	9999	seconds	
<i>rES</i>	Manual reset (appears when <i>t<sub>i</sub></i> set to OFF)	0.0		0.0	100.0	%	
<i>Lcb</i>	Cutback low	Aut0		0	9999	as display	
<i>Hcb</i>	Cutback high	Aut0		0	9999	as display	
<i>rELC</i>	Relative cool gain (set 1)	1.00		0.01	9.99		



Name	Parameter Description	Default Value		Minimum	Maximum	Units	Customer Settings
		UK	USA	Value	Value		

SP	Set Point List						
SSEL	Select SP1 or SP2	SP 1	SP 1	SP1	SP2		
L-r	Local or remote setpoint select	Loc	Loc	Loc	rmt		
SP 1	Setpoint 1 value	25	70	As display range			
SP 2	Setpoint 2 value	25	70	As display range			
rmt.SP	Remote setpoint	0	0	As display range			
Loc.t	Local trim	0	0	As display range			
SP 1.L	Setpoint 1 low limit	0	32	As display range			
SP 1.H	Setpoint 1 high limit	1000	2 100	As display range			
SP 2.L	Setpoint 2 low limit	0	-32	As display range			
SP 2.H	Setpoint 2 high limit	1000	2 100	As display range			
Loc.L	Local setpoint trim low limit	-2 10	-346	As display range			
Loc.H	Local setpoint trim high limit	1200	2 192	As display range			
SPrr	Setpoint rate limit	OFF	OFF	As display range			
dwEll	Dwell time	OFF	OFF	0.1 to 999.9 minutes			
End.t	End type	rES	rES			Hold	Stby
Prog	Program control	rES	rES			rES	
Stat	Status of program					run	rES



Name	Parameter Description	Default Value		Minimum Value	Maximum Value	Units	Customer Settings
		UK	USA				

<i>i P</i>	Input list						
<i>F<sub>LT</sub></i>	Input filter time constant	1.6	1.6	0.0 Off*	999.9	secs	
<i>OFFSE</i>	PV Offset			-999	9999	as display	
The next 5 parameters will appear if User calibration has been enabled in configuration level. To perform a user calibration refer to Ch 6.							
<i>CAL</i>	FACT will re-instate factory settings and disable User Calibration. Default setting FACT USER will re-instate any previously set User Calibration offsets and make available User Calibration parameters as follows:						
<i>CALS</i>	User calibration select	none	none				Hi, Lo, none
<i>ADJ<sup>o</sup></i>	Adjust calibrated reference source						
The following two parameters are always present in Full Access level but not in Operator level							
<i>CJC<sup>o</sup></i>	Cold Junction compensation temperature						
<i>mV</i>	Millivolt input						
* Do not make adjustments to the <i>ADJ</i> parameter unless you wish to offset the controller calibration.							



$\alpha P$	<b>Output list</b>	Note; If On/Off control is configured only <i>Sb.OP</i> , <i>on.t.H</i> and <i>on.t.C</i> will appear in the following list				
<i>OP.Lo</i>	<u>L</u> ow (power) <u>o</u> utput limit	<i>0.0</i> or <i>- 100.0</i> (cool)	<i>- 100.0</i>	<i>100.0</i>	%	
<i>OP.Hi</i>	<u>H</u> igh (power) <u>o</u> utput limit	<i>100.0</i>	<i>100.0</i>	<i>- 100.0</i>	<i>100.0</i>	%
<i>Sb.OP</i>	<u>O</u> utput setting when in <u>s</u> ensor <u>b</u> reak	<i>0.0</i>		<i>- 100.0</i>	<i>100.0</i>	%
<sup>1</sup> <i>CYC.H</i>	<u>H</u> eat <u>c</u> ycle time	<i>1.0</i> (logic) <i>20</i> (relay)	<i>0.2</i>	<i>999.9</i>	secs	
<i>on.t.H</i>	<u>H</u> eat output min. <u>o</u> n <u>t</u> ime	<i>0.1</i>	<i>0.1</i>	<i>RuLo</i> (50mS)	<i>1.0</i>	secs
<sup>1</sup> <i>CYC.C</i>	<u>C</u> ool <u>c</u> ycle time	<i>1.0</i> (logic) <i>20</i> (relay)	<i>0.2</i>	<i>999.9</i>	secs	
<sup>1</sup> <i>on.t.C</i>	<u>C</u> ool output min. <u>o</u> n <u>t</u> ime	<i>0.1</i>	<i>0.1</i>	<i>RuLo</i> (50mS)	<i>1.0</i>	secs
<i>m.t.r</i>	VP motor travel time			<i>0.0</i>	<i>999.9</i>	

\* A minimum filter time of 1.0 seconds is recommended to provide sufficient noise immunity.

<sup>1</sup> Are not used for value position control.



Name	Parameter Description	Default Value		Minimum	Maximum	Units	Customer Settings
		UK	USA	Value	Value		

<b>OnOff</b>	<b>On/off list</b>						
This set of parameters only appear if On/Off control has been configured							
<i>hYS.H</i>	Heat hysteresis	0	0	0	9999	as display	
<i>hYS.C</i>	Cool hysteresis	0	0	0	9999	as display	
<i>HC.db</i>	Heat/Cool dead band	1	1	0	9999	as display	

<b>com5</b>	<b>Comms list</b>						
<i>Addr</i>	Communications address	1	1	1	254		

<b>ACCESS</b>	<b>Access list</b>						
<i>codE</i>	Full and Edit level password	1	1	0	9999		
<i>Goto</i>	Goto level -OPER, FULL, Edit or CONF	OPER	OPER	OPER	CONF		
<i>CONF</i>	Configuration level password	2	2	0	9999		




### SETTING ALARM LEVELS

Up to 4 Alarms may be configured. Each alarm is given a name to describe its function - see table below:

If an alarm is not used it does not appear in the list below.

In place of dashes, letters indicate alarm type as follows:

- FSL Full Scale Low
- FSH Full Scale High
- dEu Deviation Band
- dHi Deviation High
- dLo Deviation Low
- Lcr Low current
- Hcr High current



## Diagnostic alarms

These indicate that a fault exists in either the controller or the connected devices.

Display shows	What it means	What to do about it
<i>EEr</i>	<i>Electrically Erasable Memory Error:</i> The value of an operator or configuration parameter has been corrupted.	This fault will automatically take you into configuration level. Check all of the configuration parameters before returning to operator level. Once in operator level, check all of the operator parameters before resuming normal operation. If the fault persists or occurs frequently, contact Eurotherm Controls.
<i>S.br</i>	<i>Sensor Break:</i> Input sensor is unreliable or the input signal is out of range.	Check that the sensor is correctly connected.
<i>L.br</i>	<i>Loop Break:</i> The feedback loop is open circuit.	Check that the heating and cooling circuits are working properly.
<i>LdF</i>	<i>Load failure</i> Indication that there is a fault in the heating circuit or the solid state relay.	This is an alarm generated by feedback from a Eurotherm TE10S solid state relay (SSR) operating in PDSIO® SSRx Load Doctor-see <i>Electrical installation</i> Chapter 2. It indicates either an open or short circuit SSR, blown fuse, missing supply or open circuit heater.
<i>SSr.F</i>	<i>Solid state relay failure</i> Indication that there is a fault in the solid state relay	This is an alarm generated by feedback from a Eurotherm TE10S solid state relay (SSR) operating in PDSIO® SSRx Enhanced Load Doctor-see <i>Electrical installation</i> Chapter 2. It indicates either an open or short circuit condition in the SSR.
<i>Hr.F</i>	<i>Heater failure</i> Indication that there is a fault in heating circuit	This is an alarm generated by feedback from a Eurotherm TE10S solid state relay (SSR) operating in PDSIO® SSRx Enhanced Load Doctor -see <i>Electrical installation</i> Chapter 2. It indicates either a blown fuse, missing supply or open circuit heater.
<i>HwEr</i>	<i>Hardware error</i> Indication that a module is of the wrong type, missing or faulty	Check that the correct modules are fitted.

Figure 1.13a Diagnostic alarms - continued on the next page



### Diagnostic alarms continued

These indicate that a fault exists in either the controller or the connected devices.

Display shows	What it means	What to do about it
$\Pi \square . 1 \square$	<i>No I/O module</i> Modules are configured but not fitted	Fit module
$r m E F$	<i>Remote input failure.</i> The PDSIO® input is open circuit (PDSIO modes also known as SST Smart Setpoint Transmission)	Check for open or short circuit wiring on the PDSIO® input
$LLLL$	<i>Out of Display range, low reading</i>	Check the value of the display range
$HHHH$	<i>Out of Display range, high reading</i>	Check the value of the display range
$Err 1$	<i>Error 1: ROM self-test fail</i>	Return the controller for repair
$Err 2$	<i>Error 2: RAM self-test fail</i>	Return the controller for repair
$Err 3$	<i>Error 3: Watchdog fail</i>	Return the controller for repair
$Err 4$	<i>Error 4: Keyboard failure</i> Stuck button, or a button was pressed during power up.	Switch the power off and then on without touching any of the controller buttons.
$Err 5$	<i>Error 5: Input circuit failure</i>	Return the controller for repair*
$Pwr F$	<i>Power failure.</i> The line voltage is too low	Check that the supply to the controller is within the rated limits

**Figure 1.13b Diagnostic alarms**


\* If the user has disassembled and reassembled the instrument, this error can occur if any connectors are not seated properly.



## Chapter 2 INSTALLATION

	<b>PAGE</b>
<b>Instrument Layouts</b> .....	<b>2-2</b>
<b>Introduction</b> .....	<b>2-4</b>
<b>Mechanical Installation</b> .....	<b>2-4</b>
<b>Wiring</b> .....	<b>2-5</b>
<b>Outputs 1 and 2 Connection</b> .....	<b>2-7</b>
<b>Communication Connections</b> .....	<b>2-8</b>
<b>Typical Wiring Diagram</b> .....	<b>2-9</b>




**INSTRUMENT LAYOUT****KEY**

1. Display screen
2. Latching ears
3. Panel sealing gasket
4. Panel retaining clips
5. Label
6. Sleeve
7. Terminal covers
8. Ratchets

**Figure 2-1 2216e 1/16 DIN controller**

**Outline dimensions Model 2216e**



**Figure 2-2 Outline dimensions Model 2216e controller**

The controller plugs into a plastic sleeve, which in turn fits into the panel cutout shown above.



## INTRODUCTION

The Model 2216e is a precision temperature controller with self tuning. It has a modular hardware construction which provides two control outputs, one alarm relay and one communications port.

### Controller labels

The labels on the sides of the controller identify the ordering code, the serial number, and the wiring connections.

Appendix A, *Understanding the Ordering Code* explains the hardware and software configuration of your particular controller.

## MECHANICAL INSTALLATION

### To install the controller

1. Cut the panel to the relevant hole size shown in Figure 2-3 and 2.4.
2. Insert the controller through the front of this cutout.
3. Spring the upper and lower panel retaining clips into place. Secure the controller in position by holding it level and pushing both retaining clips forward.

### NOTE



If the panel retaining clips subsequently need removing, they can be unhooked from the side with either your fingers or a screwdriver

### Unplugging and plugging-in the controller

The controller can be unplugged from its sleeve by easing the latching ears outwards and pulling it forward out of the sleeve. When plugging the controller back into its sleeve, ensure that the latching ears click into place to maintain the IP 65 sealing.



## WIRING

Please read Appendix B, Safety and EMC information before proceeding.

### WARNING

Please ensure that the controller is correctly configured for your application. Incorrect configuration could result in damage to the process being controlled, and/or personal injury. The controller may either have been configured when ordered, or may need configuring now. See Chapter 5, *Configuration*.




Figure 2-3 Model 2216e wiring connections

\* The ground connection is not required for electrical safety but must be connected to satisfy EMC requirements.

### Wire Sizes

All electrical connections are made to the screw terminals at the rear of the controller. They accept wire sizes from 0.5 to 1.5 mm<sup>2</sup> (16 to 22 AWG), and are protected by a hinged cover to prevent hands or metal making accidental contact with live wires. Rear terminals should be tightened to a torque of 0.4Nm (3.5 lb in).

### Wiring connections

The wiring connections are shown in Figure 2-3.

Outputs 1 and 2 are factory fitted modules which can be any one of the types shown in figure 2-8. Check the ordering code on the controller side label to determine which have been fitted.



### Sensor input connections

The connections for the various types of input are as follows:




Fig 2-7 Sensor input connections

### OUTPUTS 1 AND 2 CONNECTIONS

Outputs 1 and 2 can be any one of the types shown in the table below, configured to perform any one of the functions shown.

To check which outputs are installed, and their configuration, refer to the ordering code and the wiring information on the controller side labels.

Module type	Connections				Possible functions
	Output 1		Output 2		
	1A	1B	2A	2B	
Relay: 2-pin (2A, 264 Vac max.)					Heating Cooling Alarms
Logic: non-isolated* (18Vdc at 24mA)					+PDSIO® modes 1or 2 (SSRx Load Doctor Functions) Heating Cooling Alarms
Triac (1A, 30 to 264Vac)					Heating or cooling
DC control: isolated (18Vdc, 20mA max)			DC not available in output 2		PID Heating or cooling

\*Logic can also be configured as logic input on module 2A.

+PDSIO® Mode 1 & 2 are only supported in Output 1.

Figure 2-8 Outputs 1 and 2 connections



## PDSIO® modes

**PDSIO®** is a proprietary technique developed by Eurotherm for bi-directional communication over a single pair of wires. There are several operating modes.

In **SSRx Load Doctor** a logic output delivers a power demand signal to a TE10 solid state relay (SSR) and the SSR responds with a single load circuit failure message.

In **SSRx Enhanced Load Doctor** a logic output delivers a power demand signal to an SSR and the SSR responds with the ON state RMS load current, and two fault messages - SSR failure or heater circuit failure.

## Snubbers

The controller is supplied with 'snubbers' (15nF +100Ω) which should be wired across the relay or triac outputs when switching inductive loads such as mechanical contactors and solenoid valves. The snubbers are used to prolong contact life and to suppress interference when switching such loads.

Snubbers pass 0.6mA at 110Vac and 1.2mA at 240Vac, which may be sufficient to hold in high impedance relay coils. They should not, therefore, be used in such installations.

### WARNING

**When a relay contact is used in an alarm circuit ensure that the current passing through the snubber when the relay contact is open does not hold in low power electrical loads and thereby interfere with the failsafe operation of the alarm circuit.**

## COMMUNICATION CONNECTIONS

The communication option can be either of four types shown in the table below


Communications type	Connection				
	HB	HC	HD	HE	HF
4-wire EIA-422 serial communications*	A' (RX +)	B' (RX -)	Common	A (TX +)	B (TX -)
EIA-232 serial communications	Not used	Not used	Common	A	B
PDSIO™ Setpoint input (SST)	Not used	Not used	Not used	Signal	Common
2-wire EIA-485 Serial Communications	Not used	Not used	Common	A (TX +) (RX +)	B (TX -) (RX -)

**Figure 2-9 Communication connections**

\*The 4-wire EIA-422 communication board can be modified to support 2-wire 485 communication. Please consult factory.



**Wiring of EIA-485 serial communication links**



Standard EIA-485 is a 2-wire connection which allows up to 32 controllers to be multi-dropped from a single communications link over a distance of up to 1.2Km. To ensure reliable operation of the communications link, (without data corruption due to noise or line reflections) the connections between the controller should be made using a twisted pair of wires inside a shielded cable with the connections terminated with resistors in the manner shown in this diagram. This diagram also shows the use of a converter to connect the 2-wire EIA-485 link into a standard EIA-232 computer port.

Note:  
 All termination resistors are 220 ohm 1/4W carbon composition.  
 Local grounds are at equipotential. Where equipotential is not available wire into separate zones using a galvanic isolator.

**Figure 2-10 2-wire EIA-485 wiring**



**TYPICAL WIRING DIAGRAM**




Fig 2-8 Typical wiring diagram, Model 2216e Controller



# Chapter 3 ACCESS LEVELS

	<b>PAGE</b>
<b>The Different Access Levels</b> .....	<b>3-2</b>
<b>Selecting an Access Level</b> .....	<b>3-3</b>
<b>Edit Level</b> .....	<b>3-5</b>



This chapter describes the different levels of access to the operating parameters within the 2208e and 2204e controller.

There are three topics:

- THE DIFFERENT ACCESS LEVELS
- SELECTING AN ACCESS LEVEL
- EDIT LEVEL

## THE DIFFERENT ACCESS LEVELS

Access level	Display shows	What you can do	Password Protection
Operator	<i>OPER</i>	In this level operators can view and adjust the value of parameters defined in Edit level (see below).	No
Full	<i>FULL</i>	In this level all the parameters relevant to a particular configuration are visible. All alterable parameters may be adjusted.	Yes
Edit	<i>EDIT</i>	In this level you can set which parameters an operator in Operator level is able to view and adjust. You can hide or reveal complete lists and individual parameters within each list, and you can make parameters read-only or alterable. You can also promote parameters to the home list. (See <i>Edit level</i> at the end of the chapter).	Yes
Configuration	<i>CONF</i>	This special level allows access to set up the fundamental characteristics of the controller.	Yes


**Figure 3-1 Access levels**



## SELECTING AN ACCESS LEVEL

Access to Full, Edit or Configuration levels is protected by a password to prevent unauthorised access.

If you need to change the password, see Chapter 5, *Configuration*



### Access list header

Press  until you reach the access list header 'AccS'.

Press the Scroll button

### Password entry

The password is entered from the 'Code' display.

Enter the password using the  or  buttons. Once

the correct password has been entered, there is a two second delay after which the lower readout will change to show 'PASS' indicating that access is now unlocked.

The pass number is set to '1' when the controller is shipped from the factory.

*Note;* A special case exists if the password has been set to '0'. In this case access will be permanently unlocked and the lower readout will always show 'PASS'.


Press the Scroll button to proceed to the 'Code' display.

(If an *incorrect* password has been entered and the controller is still 'locked' then pressing *Scroll* at this point will simply return you to the *AccS* list header.)

*Note:* From this *code* display, you can access "read only" configuration level by pressing  and  together.

To escape, press  and  together.





### Level selection

The 'Goto' display allows you to select the required access level.

Use  and  to select from the following display codes: **OPER**: Operator level  
**FULL**: Full level  
**Edit**: Edit level  
**CONF**: Configuration level

Press the Scroll button

If you selected either **OPER**, **FULL** or **Edit** level you will be returned to the **ACC S** list header in the level that you chose. If you selected **CONF**, you will get an alternative display showing **CONF** in the upper readout (see below).

### Configuration password

When the **CONF** display appears, you must enter the Configuration password in order to gain access to Configuration level. Do this by repeating the password entry procedure described in the previous section. The configuration password is set to '2' when the controller is shipped from the factory. If you need to change the configuration password, see Chapter 5, *Configuration*.

Press the Scroll button

### Configuration level

The first display of configuration is shown. See chapter 5, *Configuration* for details of the configuration parameters. For instructions on leaving configuration level see Chapter 5, *Configuration*.



## Returning to Operator Level

To return to operator level from either 'FULL' or 'Edit' level, repeat entry of the password and select 'OPER' on the 'Go to' display.

In 'Edit' level the controller will automatically return to operator level if no button is pressed for 45 seconds.

## EDIT LEVEL

Edit level is used to set which parameters you can see and adjust in Operator level. It also gives access to the 'Promote' feature which allows you to select and add ('Promote') up to twelve parameters into the Home display list, thereby giving simple access to commonly used parameters.

### Setting operator access to a parameter

First you must select Edit level, as shown on the previous page.

Once in Edit level you select a list or a parameter within a list in the same way as you would in Operator or Full level. That is, you move from list header to list header by pressing the Page button, and from parameter to parameter within each list using the Scroll button.

**However, in Edit level what is displayed is not the value of a selected parameter but a code representing the parameter's availability in Operator level.**

When you have selected the required parameter, use the  and  buttons to set its availability in operator level.

There are four codes:

**ALtEr** Makes a parameter alterable in Operator level

**PrO** Promotes a parameter into the Home display list

**rEAd** Makes a parameter or list header read-only (*it can be viewed but not altered*)

**Hi dE** Hides a parameter or list header.

For example:



The parameter selected is the set point for Alarm  
2 - Full Scale Low

It will be alterable in Operator level



### Hiding or revealing a complete list

To hide a complete list of parameters, all you have to do is hide the list header. If a list header is selected only two selections are available: *rEAd* and *Hi dE*.

(It is not possible to hide the *ACC5* list which will always display the code: *Li SE*.)

### Promoting a parameter

Scroll through the lists to the required parameter and choose the *Prm* code. The parameter is then automatically added (promoted) into the Home display list (the parameter will also be accessible as normal from the standard lists. a maximum of 16 parameters can be promoted. Promoted parameters are automatically 'alterable'.



# Chapter 4 TUNING

	<b>PAGE</b>
<b>What is Tuning?</b> .....	<b>4-2</b>
<b>Automatic Tuning</b> .....	<b>4-3</b>
<b>Manual Tuning</b> .....	<b>4-6</b>



Before tuning please read Chapter 1, *Operation*, to learn how to select and change a parameter.

This chapter has three main topics:

- WHAT IS TUNING?
- AUTOMATIC TUNING
- MANUAL TUNING

## WHAT IS TUNING?

In tuning you match the characteristics of the controller to that of the process being controlled in order to obtain good control. Good control means:

Stable 'straight-line' control of the temperature at setpoint without fluctuation

Acceptable overshoot or undershoot of the temperature setpoint

Quick response to deviations from the setpoint caused by external disturbances, thereby restoring the temperature rapidly to the setpoint value.

Tuning involves calculating and setting the value of the parameters listed in Table 4-1. These parameters appear in the *PID* list.

Parameter	Code	Meaning or Function
Proportional band	$Pb$	The bandwidth in display units over which the output power is proportioned between minimum and maximum.
Integral time	$t_i$	Determines the time taken by the controller to remove steady-state error signals.
Derivative time	$t_d$	Determines how strongly the controller will react to the rate-of-change of the measured value.
Low cutback	$Lcb$	The number of display units below setpoint at which the controller will cutback the output power in order to prevent overshoot on heat up.
High Cutback	$Hcb$	The number of display units above setpoint at which the controller will increase the output power in order to prevent undershoot on cool down.
Relative cool gain	$rELC$	Only present if cooling has been configured. Sets the cooling proportional band by dividing the $Pb$ value by the $rELC$ value.

**Table 4-1 Tuning parameters**



## AUTOMATIC TUNING

This method automatically determines the value of the parameters listed in table 4-1 on the previous page.

The 2216e uses a 'one-shot' tuner which works by switching the output on and off to induce an oscillation in the measured value. From the amplitude and period of the oscillation, it calculates the tuning parameter values.

If the process cannot tolerate full heating or cooling being applied during tuning, then the level of heating or cooling can be restricted by setting the heating and cooling power limits in the Output list. However, the measured value *must* oscillate to some degree for the tuner to be able to calculate values

A One-shot Tune can be performed at any time but normally it is performed only once during the initial commissioning of the process. However, if the process under control subsequently becomes unstable (because its characteristics have changed), you can re-tune again for the new conditions.

It is best to start tuning with the process at ambient temperature. This allows the tuner to calculate more accurately the low cutback and high cutback values that restrict the amount of overshoot or undershoot.

### Heating and Cooling Output Cycle Times

Before commencing a tuning cycle, set the values of  $EYCH$  (heat cycle time) and  $EYCL$  (cool cycle time) in the op (output list). These values apply if you are using a logic, relay or triac output. They have no effect on a DC output.

A logic output switching a solid state relay can be set to values such as 1 sec.

A relay or triac output should be set to 20 sec.



## How to tune


1. Set the setpoint to the value at which you will normally operate the process.
2. In the 'ΑΕΛΟΝ' list, select 'ΕΤΟΝΕ' and set it to 'ON'
3. Press the Page and Scroll buttons together to return to the Home display. The display will flash 'ΕΤΟΝΕ' to indicate that tuning is in progress.
4. The controller will induce an oscillation in the temperature by turning the heating on and then off. The first cycle will not complete until the measured value has reached the required setpoint.
5. After two cycles of oscillation the tuning will be completed and the tuner will switch itself off.
6. The controller will then calculate the tuning parameters listed in Table 4-1 and will resume normal control action.

If you want 'Proportional only' or 'PD' or 'PI' control, you should set the 'Ε<sub>1</sub>' or 'Ε<sub>2</sub>' parameters to **OFF** before commencing the tuning cycle. The tuner will leave them off and will not calculate a value for them.

For valve position tuning and set-up, please refer to Appendix D.



### Typical automatic tuning cycle



### Calculation of the cutback values

*Low cutback* and *High cutback* are values that restrict the amount of overshoot or undershoot that occur during large step changes in temperature (for example, under startup conditions).

If either low cutback or high cutback is set to 'Auto' the values will be fixed at three times the proportional band, and will not be changed during automatic tuning.



## MANUAL TUNING

If for any reason automatic tuning gives unsatisfactory results, you can tune the controller manually. There are a number of standard methods for manual tuning. The one described here is the Ziegler-Nichols method.

With the process at its normal running temperature:

1. Set the Integral Time ' $t_i$ ' and the Derivative Time ' $t_d$ ' to *OFF*.
2. Set High Cutback and Low Cutback, ' $Hcb$ ' and ' $Lcb$ ', to *Auto*
3. Ignore the fact that the temperature may not settle precisely at the setpoint
4. If the temperature is stable, reduce the proportional band ' $Pb$ ' so that the temperature just starts to oscillate. If the temperature is already oscillating, increase the proportional band until it just stops oscillating. Allow enough time between each adjustment for the loop to stabilise. Make a note of the proportional band value ' $B$ ' and the period of oscillation ' $T$ '.
5. Set the  $Pb$ ,  $t_i$ ,  $t_d$  parameter values according to the calculations given in Table 4-2.

Type of control	Proportional band ' $Pb$ '	Integral time ' $t_i$ '	Derivative time ' $t_d$ '
Proportional only	$2xB$	OFF	OFF
P + I control	$2.2xB$	$0.8xT$	OFF
P + I + D control	$1.7xB$	$0.5xT$	$0.12xT$

**Table 4-2 Tuning values**



### Setting the cutback values

The above procedure sets up the parameters for optimum steady state control. If unacceptable levels of overshoot or undershoot occur during start-up or for large step changes in temperature, then manually set the cutback parameters  $L_{cb}$  and  $H_{cb}$ .


Proceed as follows:

1. Set the low and high cutback values to three proportional bandwidths (that is to say,  $L_{cb} = H_{cb} = 3 \times P_b$ ).
2. Note the level of overshoot or undershoot that occurs for large temperature changes (see the diagrams below).

In example (a) increase  $L_{cb}$  by the overshoot value. In example (b) reduce  $L_{cb}$  by the undershoot value.


Example (a)

#### Temperature



Example (b)

#### Temperature



Where the temperature approaches setpoint from above, you can set  $H_{cb}$  in a similar manner.



### Integrating action and manual reset

In a full three-term controller (that is, a PID controller), the integral term 'ti' automatically removes steady state errors from the setpoint. If the controller is set up to work in two-term mode (that is, PD mode), the integral term will be set to **OFF**. Under these conditions the measured value may not settle precisely at setpoint. When the integral term is set to **OFF** the parameter *manual reset* (code **RES**) appears in the **PID SET** in 'FULL' Access level. This parameter represents the value of the power output that will be delivered when the error is zero. You may set this value manually in order to remove the steady state error.

### Automatic droop compensation (Adc)

The steady state error from the setpoint, which occurs when the integral term is set to **OFF**, is sometimes referred to as 'droop'. **Adc** automatically calculates the manual reset value in order to remove this droop. To use this facility, you must first allow the temperature to stabilise. Then, in the autotune parameter list, you must set **Adc** to '**CALLC**'. The controller will then calculate a new value for manual reset, and switch **Adc** to '**MAN**'.

**Adc** can be repeated as often as you require but between each adjustment you must allow time for the temperature to stabilise.



## Chapter 5 CONFIGURATION

	PAGE
<b>Selecting Configuration Level</b> .....	<b>5-2</b>
<b>Leaving Configuration</b> .....	<b>5-3</b>
<b>Steps Involved in Configuring a Controller</b> .....	<b>5-3</b>
<b>Navigation Diagram</b> .....	<b>5-4</b>
<b>Configuration Parameter Tables</b> .....	<b>5-6</b>

---

### WARNING

Configuration is protected and should only be carried out by an authorised person. Incorrect configuration could result in damage to the process being controlled and/or personal injury. It is the responsibility of the person commissioning the instrument to ensure that the configuration is correct.

---



### SELECTING CONFIGURATION LEVEL




Figure 5.1



## LEAVING CONFIGURATION LEVEL





Figure 5.2

## STEPS INVOLVED IN CONFIGURING A CONTROLLER


The navigation diagram which follows shows the general location of parameters which define the way in which the controller works. They are grouped under headings. The actual parameters shown in your controller may differ slightly since some appear only as a result of selecting others. A full list of possibilities is included in the PARAMETER TABLES which follow the navigation diagram.



**NAVIGATION DIAGRAM (PART A)**



**NAVIGATION DIAGRAM (PART B)**



Heading	Input/Output Functions	Wiring Terminals
The first four headings set up the controller functions as follows:		
<i>Inst Conf</i>	Sets up display and control parameters	Not applicable
<i>IP Conf</i>	Selects the input sensor type	Not applicable
<i>CAL Conf</i>	To calibrate to external reference sources	Not applicable
<i>AL Conf</i>	Sets up the alarm types	Not applicable
The remaining headings configure the controller input/output functions. The upper readout corresponds to rear terminal numbers associated with a particular i/o.		
<i>LA Lb Conf</i>	Sets up the action of the two digital inputs	LA & LB
<i>AA Conf</i>	Sets up the action of the fixed relay on output AA	AA to AC
<i>HA Conf</i>	Sets up digital comms type	HB to HF
<i>1A 2A Conf</i>	Sets up the output modules 1A and 2A	1A & 1B / 2A & 2B
<i>3A Conf</i>	Sets up the action of the fixed relay on output 3A	3A to 3C
<i>4A Conf</i>	Sets the action of the 10A output relay in 2204	4A to 6D
<i>PASS Conf</i>	To choose new passwords	
<i>EXIT NO/YES</i>	To leave configuration level and return to operator level	



## CONFIGURATION PARAMETER TABLES

Name	Parameter description	Values	Meaning
<b>Inst</b>	<b>Instrument configuration</b>		
<b>Unit</b>	Instrument units	C F K none	Centigrade (default UK) Fahrenheit (default USA) Kelvin Units are not displayed
<b>DecP</b>	Decimal places in the displayed value	none one two	None One Two
<b>Ctrl</b>	Control type	on/off PID VP	On/off control PID control VP Control
<b>Act</b>	Control action	reverse direct	Reverse acting (required for temperature control) - output decreases on approach to setpoint. Direct acting
<b>cool</b>	Type of cooling	Linear Oil H2O Fan	Linear Oil (50mS min on time) Water(non-linear) Fan (0.5S min on time)
<b>PwrF</b>	Power feedback	on off	Power feedback is on (compensates for changes in supply voltage) Power feedback is off
<b>Pdtr</b>	Bumpless manual/auto transfer when using PD control	no YES	Non-bumpless transfer Bumpless transfer (auto to manual and manual to auto)
<b>FoP</b>	Forced manual output	no YES	Bumpless manual/auto transfer Returns to the manual value that was set when last in manual mode.
<b>Sbrk</b>	Sensor break output	Sbrk Hold	Go to pre-set value (maintains output at a known, safe level) Freeze output (maintains output at value immediately before break)
<b>LCHi</b>	Load Current Scaling Factor	100	See Appendix E-10

**NOTE**

Factory default parameter values and states are included where applicable and are indicated by the shaded areas in the following tables.



Name	Parameter description	Value	Meaning
<b>i P</b>	<b>Input configuration</b>		
<b>i nPt</b>	Input type	<b>Jtc</b> <b>Ktc</b> <b>Ltc</b> <b>Rtc</b> <b>Btc</b> <b>Ntc</b> <b>Ttc</b> <b>Stc</b> <b>PL2</b> <b>rtd</b> <b>Ctc</b>  <b>mV</b> <b>volt</b>	J thermocouple (default USA) K thermocouple (default UK) L thermocouple R thermocouple (Pt/Pt13%Rh) B thermocouple (Pt30%Rh/Pt6%Rh) N thermocouple T thermocouple S thermocouple (Pt/Pt10%Rh) PL 2 thermocouple 100Ω platinum resistance thermometer. Custom downloaded input type. The default is C thermocouple, or the name of the downloaded custom input will be displayed. Linear millivolt (Also mA input via an external 2.49Ω current sense resistor) Linear voltage
	NOTE: After selecting an input type, do not forget to adjust the setpoint limits in Full Access level		
<b>rnGL</b>	Input range low		Display low range for input
<b>rnGH</b>	Input range high		Display high range for input
<b>CJC</b>	CJC ref. temperature (CJC does not appear for linear inputs)	<b>Auto</b> <b>0°C</b> <b>45°C</b> <b>50°C</b>	Automatic cold junction compensation 0°C external reference 45°C external reference 50°C external reference
Linear Input Scaling - The next 4 parameters only appear if a linear input is chosen			
<b>i nPL</b> <b>i nPH</b> <b>UALL</b> <b>UALH</b>		Input value low Input value high Displayed reading low Displayed reading high	
<b>i mP</b>	Sensor break input impedance trip level	<b>OFF</b> <b>Auto</b> <b>H1</b> <b>H1 H1</b>	Sensor break detection is disabled <i>Appears for mV or V inputs only</i> Trip level set by the sensor input table Trip level set at 7.5KΩ Trip level set at 15KΩ (must be selected when <b>volt</b> input is enabled)



Name	Parameter description	Value	Meaning
<b>CR</b>	<b>User calibration config.</b>		<b>See Chapter 6 - User calibration</b>
<b>AdJ</b>	User cal enable	<b>no</b>	User calibration is disabled
		<b>YES</b>	User calibration is enabled
<b>Pnt.L</b>	User calibration point low	<b>0</b>	This is the value (in display units) at which a User last performed a low point calibration
<b>Pnt.H</b>	User calibration point high	<b>100</b>	This is the value (in display units) at which a User last performed a high point calibration
<b>OFFS.L</b>	Low point calibration offset	<b>0</b>	Offset, in display units, at the user low calibration point 'Pnt.L'. This value is automatically calculated when performing low point calibration.
<b>OFFS.H</b>	High point calibration offset	<b>0</b>	Offset, in display units, at the user high calibration point 'Pnt.H'. This value is automatically calculated when performing a high point calibration.

\* If User calibration is enabled, then the User calibration parameters will appear in the Input list of Operator Full access level. See Chapter 6, *User calibration*.



Name	Parameter description	Values	
<b>AL</b>	<b>Alarm configuration</b>	<b>Values</b>	<b>Defaults if not specified</b>
<i>AL1</i>	Alarm 1 Type	As table A	<i>OFF</i>
<i>bLoc</i>	Alarm 1 Blocking <sup>(1)</sup>	<i>no/YES</i>	<i>no</i>
<i>Ltch</i>	Alarm 1 Latching	<i>no/Auto/mAn</i>	<i>no</i>
<i>AL2</i>	Alarm 2 Type	As table A	<i>OFF</i>
<i>bLoc</i>	Alarm 2 Blocking <sup>(1)</sup>	<i>no/YES</i>	<i>no</i>
<i>Ltch</i>	Alarm 2 Latching	<i>no/Auto/mAn</i>	<i>no</i>
<i>AL3</i>	Alarm 3 Type	As table A	<i>OFF</i>
<i>bLoc</i>	Alarm 3 Blocking <sup>(1)</sup>	<i>no/YES</i>	<i>no</i>
<i>Ltch</i>	Alarm 3 Latching	<i>no/Auto/mAn</i>	<i>no</i>
<i>AL4</i>	Alarm 4 Type	As table A	<i>OFF</i>
<i>bLoc</i>	Alarm 4 Blocking <sup>(1)</sup>	<i>no/YES</i>	<i>no</i>
<i>Ltch</i>	Alarm 4 Latching	<i>no/Auto/mAn</i>	<i>no</i>
<b>Table A: Alarm types</b>			
<i>OFF</i>	No alarm		
<i>FSL</i>	Full scale low		
<i>FSH</i>	Full scale high		
<i>dEu</i>	Deviation band		
<i>dHi</i>	Deviation high		
<i>dLo</i>	Deviation low		
<i>Lcr</i>	Low current		
<i>Hcr</i>	High current		

(1) Blocking allows the alarm to become active only after it has first entered a safe state.

**NOTE**  These are 'soft' alarms, i.e. Indication only. They would normally be attached to an output. See Chapter 7 for a step by step guide.



Name	Parameter description	Functions	Meaning
<b>HR</b>	<b>Comms module config</b>	<b>Functions</b>	<b>Meaning</b>
<i>id</i>	Identity of the option installed	<i>PdS,</i> <i>cmS</i>	PDSIO® setpoint input 2- or 4-wire EIA-485 (422) or EIA-232 comms module
<i>Func</i>	Function		
<i>Some of the following parameters may appear if one of the comms options is installed</i>			
		<i>cmS</i> <i>nonE</i>	DIGITAL Communication protocol ordered None
<i>The following parameters will appear if the PDSIO setpoint input option is installed.</i>			
		<i>nonE</i> <i>SP, P</i>	No PDSIO® function PDSIO® setpoint input
<i>URLL</i>	PDSIO® low input value	Range = -999 to 9999	
<i>URLH</i>	PDSIO® high input value	Range = -999 to 9999	
<i>The following parameters will appear if the function chosen is Mod protocol.</i>			
<i>bAud</i>	Baud Rate	1200, 2400, 4800, 9600, 19.20, 1920 (19200)	
<i>*Prty</i>	Comms Parity	<i>nonE</i> <i>EuEn</i> <i>Odd</i>	No parity Even parity Odd parity
<i>*rESn</i>	Comms Resolution	<i>FuLL</i> <i>Int</i>	Full resolution Integer resolution

\*Not used with some communication protocols. Please consult factory.



Name	Parameter description	Function	Meaning
<i>id</i>	Output 1 configuration Identity of module installed	nonE REL dC.OP LoG SSr	No module fitted Relay output DC output (isolated) Logic or PDSIO® output Triac output
<i>Func</i>	Function  <i>Only appear for id = dC.OP</i>  <i>Only appear for id = dC.OP</i>  <i>Only appear for id = dC.OP</i> <i>Only appear for id = dC.OP</i> <i>Only appear for id = LoG</i> <i>Only appear for id = LoG</i>	nonE di.G HEAT COOL OP PU Err wSP SSr.1 SSr.2	Module does not operate Function set by <i>di.G.F</i> Heating output Cooling output Retransmission of output demand Retransmission of Process Value Retransmission of error Retransmission of setpoint PDSIO® mode heating PDSIO® mode 2 heating
For <i>Function = di.G</i> go to table B below			
<i>SEN5</i>	Sense of output	nor inu	Normal (e.g.heating and cooling) Inverted (alarms - de-energise in alarm)
DC output scaling For id = dC.OP the following parameters appear			
<i>OUT.L</i>	DC output minimum	0mA to 20mA	
<i>OUT.H</i>	DC output maximum	0mA to 20mA	



<b>Table B</b> The following parameters appear if 'd <sub>1</sub> G' is chosen as the function.			
<b>d<sub>1</sub> G.F</b>	Digital output functions Any number of the functions listed can be combined on to the output. Use the  and  buttons to select a desired digital function. After two seconds the display will blink and return to the 'noch' display. Use the arrows again to scroll through the function list. The previously selected function display will show two decimal points indicating that it has been added to the output.	<i>noch</i> <i>cLr</i> <i>1 - - - *</i> <i>2 - - - *</i> <i>3 - - - *</i> <i>4 - - - *</i> <i>mAn</i> <i>Sbr</i> <i>Lbr</i> <i>HErF</i> <i>Ld.F</i> <i>ENd</i> <i>SPAn</i> <i>SSrF</i> <i>NEWAL</i> <i>rmtF</i> <i>CT.OP</i> <i>CT.Sh</i>	No change Clear all existing functions Alarm 1 * Alarm 2 * Alarm 3 * Alarm 4 * Manual/Auto Sensor Break Loop Break Heater Fail Load Fail END Program PV Out of Range PDSIO@ SSR Failure New Alarm Remote Sp Fail CTx open circuit Ctx short circuit

\* From previous page. In place of the dashes, the last three characters indicate the alarm type as per table A in the AL list: eg *IFSL* = Full Scale Low. If an alarm is not configured the displayed name will differ: e.g. *AL 1* will be shown, for the first alarm.

Name	Parameter description	Function	Meaning
<b>2A</b>	<b>Output 2 configuration</b>	<b>Function</b>	<b>Meaning</b>
<i>i d</i>	Identity of module installed	<i>nonE</i> <i>rELY</i> <i>LoG</i> <i>SSr</i>	No module fitted Relay output Logic Triac output
<i>Func</i>	Function	<i>nonE</i>	none
	Outputs	<i>d<sub>1</sub> G</i> <i>HEAr</i> <i>COOL</i>	Function set by <i>d<sub>1</sub> G.F</i> Heating output Cooling output
	Logic Inputs	<i>mAn</i> <i>rmt</i> <i>SP.2</i> <i>EH</i> <i>AcAL</i> <i>StBY</i>	Manual mode select Remote setpoint select Setpoint 2 select Integral hold Acknowledge alarms Standby - ALL outputs = OFF
For <i>Func = d<sub>1</sub> G</i> (Refer to table B on page 5-13).			
<i>SEnS</i>	Sense of output	<i>nor</i> <i>inu</i>	Normal ( <i>heat and cool outputs</i> ) Inverted ( <i>alarms - de-energise in alarm</i> )



<b>PASS</b>	<b>Password list</b>
<i>FULL.P</i>	FuLL or Edit level password
<i>cnf.P</i>	Configuration level Password

<b>EXIT</b>	<b>Exit Configuration</b>	<i>no/YES</i>
-------------	---------------------------	---------------



## Chapter 6 USER CALIBRATION

	<b>PAGE</b>
<b>What is the Purpose of User Calibration?</b> .....	<b>6-2</b>
<b>User Calibration Enable</b> .....	<b>6-3</b>
<b>Single Point Calibration</b> .....	<b>6-4</b>
<b>Two Point Calibration</b> .....	<b>6-5</b>
<b>Calibration Points and Calibration Offsets</b> .....	<b>6-6</b>



This chapter has five topics:

- WHAT IS THE PURPOSE OF USER CALIBRATION?
- USER CALIBRATION ENABLE
- SINGLE POINT CALIBRATION
- TWO POINT CALIBRATION
- CALIBRATION POINTS AND CALIBRATION OFFSETS

To understand how to select and change parameters in this chapter you will need to have read Chapter 2 - *Operation*, Chapter 3- *Access Levels* and Chapter 5 - *Configuration*.

## **WHAT IS THE PURPOSE OF USER CALIBRATION?**

The basic calibration of the controller is highly stable and set for life. User calibration allows you to offset the 'permanent' factory calibration to either:

1. Calibrate the controller to your reference standards
2. Match the calibration of the controller to that of a particular transducer or sensor input
3. Calibrate the controller to suit the characteristics of a particular installation.


User calibration works by introducing zero and span offsets onto the factory set calibration. The factory set calibration can always be retrieved.



## USER CALIBRATION ENABLE

The User calibration facility must first be enabled in configuration level by setting the parameter 'Adj' in the CAL CONF list to 'YES'. This will make the User calibration parameters appear in Operator 'FULL' level.

Select configuration level as shown in Chapter 5, Configuration



### The User calibration configuration List

Press  until you reach the 'CAL CONF list

Press the Scroll button until you reach

### User calibration enable

Use  or  to select:

YES: Calibration enable

no: Calibration disabled

Press  and  together to go to the Exit display

### Exit configuration

Use  or  to select 'YES' and return to Operator level.




## SINGLE POINT CALIBRATION

Your controller is calibrated for life against known reference sources during manufacture. A calibration offset is often used to allow the controller to compensate for sensor and other system errors. The normal procedure is to set up the system under test against a known independent reference, as follows:

Set up the process to be calibrated such that the known reference displays the required value (temperature).

Observe the reading on the controller. If it is different, proceed as follows:

Select **FULL** Access level as described in Chapter 3



### Input list header

Press  until you reach the input list header.

*Press Scroll until you reach the 'CAL' display*

### Calibration type

Use  or  to select either 'FACT' or 'USER'.  
 Selecting 'FACT' will reinstate the factory calibration and hide the following User calibration parameters.  
 Selecting 'USER' will reinstate any previously set User calibration and make available the User parameters, as follows:


*Press the Scroll button*

### Calibrate low point?

Use  or  to select 'YES'.  
 Selecting 'no' will hide the next parameter

*Press the Scroll button  
continued on the next page*





### Adjust the low point calibration

The controller will display the current measured input value in the lower readout.

Use  or  to adjust the reading to the reference source value, if different.

After a two second delay the display will blink and the reading will change to the new, calibrated value. You can calibrate at any point over the entire display range

This is a single point calibration which applies a fixed offset over the full display range of the controller.

The calibration is now complete. You can return to the factory calibration at any time by select 'FACT' in the CAL display shown earlier.

Press  and  together to return to the Home display

To protect the calibration against unauthorised adjustment return to Operator level and make sure that the calibration parameters are hidden. Parameters are hidden using the 'Edit' facility describe in Chapter 3.


## TWO POINT CALIBRATION

The previous section described how to perform a single point calibration which applies a fixed offset over the full display range of the controller. A two-point calibration is used to calibrate the controller at two points and apply a straight line between them. Any readings above or below the two calibration points will be an extension of this straight line. For this reason it is best to calibrate with the two points as far apart as possible.

Proceed as follows:

1. Decide upon the low and high points at which you wish to calibrate.
2. Perform a single point calibration at the low calibration point in the manner described above
3. Set the process under calibration such that the known reference exhibits the required higher Process Value (temperature) and allow to stabilize.
4. Press the Scroll button to obtain the high calibration point as shown in the following diagrams.





**Calibrate high point?**

Use or to select 'H1'.

Press the Scroll button

**Adjust the high point calibration**

The controller will display the current measured input value in the lower readout.

Use or to adjust the reading to the reference source value, if different.

After a two second delay the display will blink and the reading will change to the new, calibrated value.

The calibration is now complete. You can return to the factory calibration at any time by select 'FACT' in the CAL display shown earlier.



To protect the calibration against unauthorised adjustment return to Operator level and make sure that the calibration parameters are hidden. Parameters are hidden using the 'Edit' facility described in Chapter 3.

**CALIBRATION POINTS AND CALIBRATION OFFSETS**

If you wish to see the points at which the User calibration was performed and the value of the offsets introduced these are shown in Configuration, under CAL CONF. The parameters are:

Name	Parameter description	Meaning
PnEL	User low calibration point	This is the value (in display units) at which a User last performed an 'Adj.L' (adjust low calibration).
PnEH	User high calibration point	This is the value (in display units) at which a User last performed an 'Adj.H' (adjust high calibration).
OFFL	Low point calibration offset	Offset, in display units, at the user low calibration point 'PnEL'.
OFFH	High point calibration offset	Offset, in display units, at the user high calibration point 'PnEH'.



## Chapter 7 ALARM CONFIGURATION

	PAGE
<b>Definition of Alarms and Events</b> .....	7-2
<b>Types of Alarms</b> .....	7-2
<b>Step 1 - Configuring the Four 'Soft' Alarms</b> .....	7-5
<b>Step 2 - Attaching an Alarm to a Physical Output</b> .....	7-6
<b>Step 3 - Grouping Alarms on a Single Output</b> .....	7-7
<b>Step 4 - Removing Alarms from an Output</b> .....	7-7

The 2200e series controllers are capable of very sophisticated alarm strategies and, although setting up of alarms has already been covered in previous chapters, this section has been included to enable operators and commissioning engineers to design their own strategies for optimum plant operation.



## DEFINITION OF ALARMS AND EVENTS

**Alarms** are used to alert an operator when a pre-set level or condition has been exceeded. They are normally used to switch an output - usually a relay - to provide interlocking of the machine or plant or external audio or visual indication of the condition.

**Soft Alarms** are indication only within the controller and are not attached to an output (relay).

**Events** - can also be alarms - but are generally defined as conditions which occur as part of the normal operation of the process. They do not generally require operator intervention.

Events are referred to as **Digital Output Functions** in the manual (see Table B, page 5-13).

For the purposes of the operation of this instrument alarms and events can be considered the same.

## TYPES OF ALARMS

The use of alarms in the 2216e controller is extremely versatile.

Up to 4 alarms can be configured. Any combination of these 4 alarms can be attached to any one or more available outputs, or any number of the available "soft" alarms can be combined to operate a single output.

### NOTE



Note: In a three term controller at least one of these outputs is used to maintain the required temperature of the process.

Outputs 1A and 2A	Are plug in modules. Normally used for control outputs, eg. Heat and Cool, but can be used for alarm outputs.
Output 3A	Is a fixed relay. Normally used for alarms or events, but can be used as control outputs.



There are seven process alarm types listed below. Alarm Types are found in configuration mode under the Alarm Config. List.

### ALARMS

<b>Full Scale High</b>	The PV exceeds a set high level
<b>Full Scale Low</b>	The PV exceeds a set low level
<b>Deviation Band</b>	The difference between PV & SP is outside a set band
<b>Deviation High</b>	The difference between PV & SP is higher than a set level
<b>Deviation Low</b>	The difference between PV & SP is lower than a set level
<b>High Current</b>	The measured current returned from a PDSIO® slave is higher than a set level
<b>Low Current</b>	The measured current returned from a PDSIO® slave is lower than a set level

Each **alarm** can be set to:

<b>Latching</b>	Alarm is indicated until acknowledged (Off, Auto, MAN)
	<b>Auto Acknowledge: (Latching Auto)</b> If the alarm is acknowledged while the alarm condition is still present, it will cause the alarm to reset as soon as the alarm condition is removed.
	<b>Manual Acknowledge: (Latching Man)</b> If the alarm is acknowledged while the alarm condition is still present, it will be ignored. A further acknowledgement is required when the alarm condition has been removed to cause the alarm to reset.
<b>Blocking</b>	Alarm occurs <b>after</b> it has been through a start up phase <b>not</b> in alarm condition.
<b>Sense Of Output</b>	Relay energised or de-energised in alarm condition.



In addition there are nine “digital output functions” used as events or alarms depending upon the requirements of the process under control:

#### **DIGITAL OUTPUT FUNCTIONS**

<b>Sensor Break`</b>	The input is open circuit
<b>Loop Break</b>	The controller does not measure a response to an output change
<b>Load Failure</b>	Used with PDSIO® Mode 1 load failure
<b>Manual</b>	Controller in manual mode
<b>PV Out Of Range</b>	Process Variable too high or too low
<b>Remote SP Fail</b>	No signal measured at the remote set point input terminals
<b>Heater Fail</b>	Used with PDSIO® Mode 2 heater open circuit
<b>SSR Fail</b>	Used with PDSIO® Mode 2 solid state relay open or short circuit
<b>Program END</b>	Signals the end of a program
<b>New Alarm</b>	Signals a new alarm

The **Sense of the Output** can be set to relay energised or de-energised in the alarm condition for any of the above functions.



### STEP1 - CONFIGURING THE FOUR 'SOFT' ALARMS

Go To Configuration Level  
Refer to Chapter 5




Figure 7.1



## STEP 2 - ATTACHING AN ALARM TO A PHYSICAL OUTPUT

This may be necessary if:

1. The instrument has been supplied un-configured or it is required to re-configure
2. Alarm relays are added




Figure 7.2



### STEP 3 - GROUPING ALARMS ON A SINGLE OUTPUT

In the previous example one alarm condition is allocated to one output relay.

The 2216e controller allow alarms and events to be grouped on to a single output. These events are shown in the table below.




Figure 7.3

### STEP 4 - REMOVING ALARMS FROM AN OUTPUT




Figure 7.4




# Appendix A

## UNDERSTANDING THE ORDERING CODE

The 2216e controller have a modular hardware construction with the option of three outputs and one communications port.


The ordering code is in two parts: the hardware code followed by the software code. The hardware code specifies the hardware build of the controller, and the software code the software configuration. The software code is optional.

UK Default	USA Default
Type KTIC 0 to 1000°C	Type JTIC 32 to 2192°F



**Hardware code**

Model number	Function	Supply voltage	Output 1	Output 2	Output 3	Comms	Manual
2216e	CC	VH	LH	RC	FL	2YM	ENG



Software code						
Sensor input	Range min	Range max	Units	Logic input 1	Logic input 2	Options
K	0 (note 2)	1000 (note 2)	C	XX	XX	CF

Sensor input	Range Min	Range Max	Units
<b>Standard sensors</b>			
J	J thermocouple	Min °C max	Min °F max
K	K thermocouple	-210 1200	-340 2192
K	K thermocouple	-200 1372	-325 2500
T	T thermocouple	-200 400	-325 750
L	L thermocouple	-200 900	-325 1650
N	N thermocouple	-200 1300	-325 2370
R	R thermocouple	-50 1768	-58 3200
S	S thermocouple	-50 1768	-58 3200
B	B thermocouple	0 1820	32 3310
P	Platinel II therm'ple	0 1369	32 2496
C	°C thermocouple W5%Re/W26%Re (Hoskins)	0 2319	32 4200
Z	RTD/PT100	-200 850	-325 1562
<b>Custom sensors (*replaces C thermocouple)</b>			
D	W3%Re/W25%Re	0 2399	32 4350
E	E thermocouple	-200 1000	-325 1830
1	Ni/Ni18%Mo	0 1399	32 2550
2	Pt20%Rh/Pt40%Rh	0 1870	32 3398
3	W/W26%Re (Englehard)	0 2000	32 3632
4	W/W26%Re (Hoskins)	0 2010	32 3650
5	W5%Re/W26%Re (Englehard)	10 2300	50 4172
6	W5%Re/W26%Re (Bucose)	0 2000	32 3632
7	Pt10%Rh/Pt40%Rh	-200 1800	392 3272
<b>Linear inputs</b>			
F	-100 to +100mV	Min -999	Max 9999
Y	0 to 20mA	-999	9999
A	4 to 20ma	-999	9999
W	0 to 5Vdc	-999	9999
G	1 to 5Vdc	-999	9999
V	0 to 10Vdc	-999	9999

Options	
Add as many options as required	
<b>Control options</b>	
DP	Direct acting PID
<b>Heating option</b>	
PD	Power feedback disabled
<b>Cooling options</b>	
XX	Linear cooling
CF	Fan cooling
CW	Water cooling
CL	Oil cooling

Logic inputs 1 & 2	
XX	Disabled
AM	Manual mode select
SR	Remote setpoint select
S2	Second setpoint
EH	Integral hold
AC	Alarm acknowledge
SB	Standby mode

Units	
C	Centigrade
F	Fahrenheit
K	Kelvin
X	Blank



**Notes:**

1. **PDSIO®** is a proprietary technique developed by Eurotherm for bi-directional communication over a single pair of wires. There are several operating modes.

In **SSRx Load Doctor** a logic output delivers a power demand signal to a TE10 solid state (SSR) relay and the SSR responds with a single load circuit failure message. Also called SSRx Load Doctor.

In **SSRx Enhanced Load Doctor** a logic output delivers a power demand signal to an SSR and the SSR responds with the ON state rms load current, and two fault messages - SSR failure or heater circuit failure. Also called SSRx Enhanced Load Doctor.

2. **Range min and Range max:** Enter a numeric value, with a decimal point if required. Thermocouple and RTD sensor inputs will always display over the full operating range shown in the sensor input table. The values entered here will act as limits for the setpoint high and low limit parameters and for alarm setpoints.
3. **Alarms** are normally supplied configured as *non-latching* and *de-energised-in-alarm*, but they can be configured as *latching*, *energised-in-alarm*, or *blocking-type* alarms (which only become active after the alarm has first entered a safe state). Up to four alarms can be combined onto a single output.



## Appendix B

### SAFETY and EMC INFORMATION

This controller is intended for industrial temperature and process control applications when it will meet the requirements of the European Directives on Safety and EMC. Use in other applications, or failure to observe the installation instructions of this handbook may impair safety or EMC. The installer must ensure the safety and EMC of any particular installation.

#### Safety

This controller complies with the European Low Voltage Directive 73/23/EEC, amended by 93/68/EEC, by the application of the safety standard EN 61010.

#### Electromagnetic compatibility

This controller conforms with the essential protection requirements of the EMC Directive 89/336/EEC, amended by 93/68/EEC, by the application of a Technical Construction File. This instrument satisfies the general requirements of the industrial environment defined in EN 50081-2 and EN 50082-2. For more information on product compliance refer to the Technical Construction File.

#### GENERAL

The information contained in this manual is subject to change without notice. While every effort has been made to ensure the accuracy of the information, Eurotherm Controls shall not be held liable for errors contained herein.

#### Unpacking and storage

The packaging should contain an instrument mounted in its sleeve, two mounting brackets for panel installation and this operating book. Certain ranges are supplied with an input adapter. If on receipt, the packaging or the instrument are damaged, do not install the product but contact your nearest Eurotherm Controls agent. If the instrument is to be stored before use, protect from humidity and dust in an ambient temperature range of  $-30^{\circ}\text{C}$  to  $+75^{\circ}\text{C}$ .

#### SERVICE AND REPAIR

This controller has no user serviceable parts. Contact your nearest Eurotherm Controls agent for repair.

#### **Caution: Charged capacitors**

Before removing an instrument from its sleeve, disconnect the supply and wait at least two minutes to allow capacitors to discharge. It may be convenient to partially withdraw the instrument from the sleeve, then pause before completing the removal. In any case, avoid touching the exposed electronics of an instrument when withdrawing it from the sleeve. Failure to observe these precautions may cause damage to components of the instrument or some discomfort to the user.



## Electrostatic discharge precautions

When the controller is removed from its sleeve, some of the exposed electronic components are vulnerable to damage by electrostatic discharge from someone handling the controller. To avoid this, before handling the unplugged controller discharge yourself to ground.

## Cleaning

Do not use water or water based products to clean labels or they will become illegible. Isopropyl alcohol may be used to clean labels. A mild soap solution may be used to clean other exterior surfaces of the product.

## INSTALLATION SAFETY REQUIREMENTS

### Safety Symbols

Various symbols are used on the instrument, they have the following meaning:



The functional earth connection is not required for safety purposes but is used to ground RFI filters.

### Personnel

Installation must only be carried out by qualified personnel.

### Enclosure of live parts

To prevent hands or metal tools touching parts that may be electrically live, the controller must be installed in an enclosure.

### Caution: Live sensors

The logic and PDSIO® outputs are electrically connected to the main PV input, (thermocouple etc.). If the temperature sensor is connected directly to an electrical heating element then these non-isolated inputs and outputs will also be live. The controller is designed to operate under these conditions. However you must ensure that this will not damage other equipment connected to these inputs and outputs and that service personnel do not touch connections to these I/O while they are live. With a live sensor, all cables, connectors and switches for connecting the sensor and non-isolated inputs and outputs must be mains rated.

## Wiring



It is important to connect the controller in accordance with the wiring data given in this handbook. Take particular care not to connect AC supplies to the low voltage sensor input or other low level inputs and outputs. Only use copper conductors for connections, (except thermocouple). Ensure that the wiring of installations comply with all local wiring regulations. For example in the in the UK, use the latest version of the IEE wiring regulations, (BS7671). In the USA, use NEC Class 1 wiring methods.

### **Power Isolation**

The installation must include a power isolating switch or circuit breaker that disconnects all current carrying conductors. The device should be mounted in close proximity to the controller, within easy reach of the operator and marked as the disconnecting device for the instrument.

### **Earth leakage current**

Due to RFI Filtering there is an earth leakage current of less than 0.5mA. This may affect the design of an installation of multiple controllers protected by Residual Current Device, (RCD) or Ground Fault Detector, (GFD) type circuit breakers.

### **Overcurrent protection**

To protect the internal PCB tracking within the controller against excess currents, the AC power supply to the controller and power outputs must be wired through the fuse or circuit breaker specified in the technical specification.

### **Voltage rating**

The maximum continuous voltage applied between any connection to ground must not exceed 264Vac.

The controller should not be wired to a three phase supply with an unearthed star connection. Under fault conditions such a supply could rise above 264Vac with respect to ground and the product would not be safe.

Voltage transients across the power supply connections, and between the power supply and ground, must not exceed 2.5kV. Where occasional voltage transients over 2.5kV are expected or measured, the power installation to both the instrument supply and load circuits should include a transient limiting device.

These units will typically include gas discharge tubes and metal oxide varistors that limit and control voltage transients on the supply line due to lightning strikes or inductive load switching. Devices are available in a range of energy ratings and should be selected to suit conditions at the installation.



## Conductive pollution

Electrically conductive pollution must be excluded from the cabinet in which the controller is mounted. For example, carbon dust is a form of electrically conductive pollution. To secure a suitable atmosphere, install an air filter to the air intake of the cabinet. Where condensation is likely, for example at low temperatures, include a thermostatically controlled heater in the cabinet.

## Grounding of the temperature sensor shield

In some installations it is common practice to replace the temperature sensor while the controller is still powered up. Under these conditions, as additional protection against electric shock, we recommend that the shield of the temperature sensor is grounded. Do not rely on grounding through the framework of the machine.

## Over-temperature protection

When designing any control system it is essential to consider what will happen if any part of the system should fail. In temperature control applications the primary danger is that the heating will remain constantly on. Apart from spoiling the product, this could damage any process machinery being controlled, or even cause a fire.

Reasons why the heating might remain constantly on include:

- the temperature sensor becoming detached from the process
- thermocouple wiring becoming short circuit;
- the controller failing with its heating output constantly on
- an external valve or contactor sticking in the heating condition
- the controller setpoint set too high.

Where damage or injury is possible, we recommend fitting a separate over-temperature protection unit, with an independent temperature sensor, which will isolate the heating circuit.

Please note that the alarm relays within the controller will not give protection under all failure conditions.

## INSTALLATION REQUIREMENTS FOR EMC

To ensure compliance with the European EMC directive certain installation precautions are necessary as follows:

- For general guidance refer to Eurotherm Controls EMC Installation Guide, HA025464.
- When using relay or triac outputs it may be necessary to fit a filter suitable for suppressing the conducted emissions. The filter requirements will depend on the type of load. For typical applications we recommend Schaffner FN321 or FN612.
- If the unit is used in table top equipment which is plugged into a standard power socket, then it is likely that compliance to the commercial and light industrial emissions standard is required. In this case to meet the conducted emissions requirement, a suitable mains filter should be installed. We recommend Schaffner types FN321 and FN612.



**Routing of wires**

To minimise the pick-up of electrical noise, the low voltage DC connections and the sensor input wiring should be routed away from high-current power cables. Where it is impractical to do this, use shielded cables with the shield grounded at both ends. In general keep cable lengths to a minimum.



**TECHNICAL SPECIFICATION****Input**

General	Range	$\pm 100\text{mV}$ and 0 to 10Vdc (auto ranging)
	Sample rate	9Hz (110mS)
	Calibration accuracy	0.25% of reading, $\pm 1$ LSD, $\pm 1^\circ\text{C}/\text{F}$
	Resolution	$<1\mu\text{V}$ for $\pm 100\text{mV}$ range, $<0.2\text{mV}$ for 10Vdc range
	Linearisation accuracy	$<0.1\%$ of reading
	Input filter	1.0 to 999.9 secs
Thermocouple	Zero offset	User adjustable over the fully display range
	Types	Refer to Sensor inputs and display ranges table
	Cold junction compensation	Automatic compensation typically $>30$ to 1 rejection of ambient temperature change (incorporates INSTANT ACCURACY™ cold junction sensing technology). External references 32, 113 and 122°F (0, 45 and 50°C)
RTD/PT100	Type	3-wire, Pt100 DIN43760
	Bulb current	0.2mA
	Lead compensation	No error for 22 ohms in all 3 leads
Process	Linear	$\pm 100\text{mV}$ , 0 to 20mA or 0 to 10Vdc (All configurable between limits)

**Outputs**

Relay	Rating: 2-pin relay	Min: 12V, 100mA dc Max: 2A, 264Vac resistive
	Rating: change-over, alarm relay	Min: 6V, 1mA dc Max: 2A, 264Vac resistive
Logic	Application	Heating, cooling or alarms
	Rating	18Vdc at 24mA (non-isolated)
Triac	Application	Heating, cooling or alarms
		PDSIO® mode 1: SSRx Load Doctor™ logic heating with load failure alarm
		PDSIO® mode 2: SSRx Enhanced Load Doctor™ logic heating with load/SSC failure alarms and load current display
Analog	Rating	1A, 30 to 264Vac resistive
	Application	Heating or cooling
	Range	Isolated, 0 to 20mA 0 to 10Vdc (configurable between limits)
	Application	Heating or cooling

**Communications**

Digital	Transmission standard	EIA-485 2wire, EIA-422 4 wire or EIA-232 at 1200, 2400, 4800, 9600, 19,200 baud
	Protocols	Modbus®
PDSIO®	Setpoint input	Setpoint input from master PDSIO® controller



**Control functions**

Control	Modes	PID or PI with overshoot inhibition, PD, PI, P only or On/Off
	Application	Heating and cooling
	Auto/manual	Bumpless transfer
	Setpoint rate limit	0.01 to 99.99 degrees or display units per minute
	Cooling algorithms	Linear; Water (non-linear); Fan (minimum on time), Oil, proportional only
Tuning	One-shot tune	Automatic calculation of PID and overshoot inhibition parameters
	Automatic droop compensation	Automatic calculation of manual reset value when using PD control
Alarms	Types	Full scale high or low. Deviation high, low, or band
	Modes	Latching or non-latching. Normal or blocking action
		Up to four process alarms can be combined onto a single output

**General**

Display	Dual, 4 digit x 7 segment high intensity LED
Dimensions and weight	1.89W x 1.89H x 4.06D in (48W x 48H x 103Dmm) 8.82oz (250g)
Supply	85 to 264Vac -15%, +10%. 48 to 62Hz. 10watts max
Temperature and RH	Operating: 32 to 131°F (0 to 55°C), RH: 5 to 90% non-condensing. Storage: 14 to 158°F (-10 to 70°C)
Panel sealing	IP 65
Electromagnetic compatibility	Meets generic emissions standard EN50081-2 for industrial environments Meets general requirements of EN50082-2(95) standards for industrial environments
Safety standards	EN61010, installation category 2 (voltage transients must not exceed 2.5kV)
Atmospheres	Electrically conductive pollution must be excluded from the cabinet in which this controller is mounted. This product is not suitable for use above 6,562ft (2000m) or in corrosive or explosive atmospheres without further protection.



## Appendix C

### North America:

EUROTHERM CONTROLS INC

Eurotherm Controls Inc  
11485 Sunset Hills Road  
Reston, VA 20190-5286

Tel: (703) 471-4870  
Fax: (703) 787-3436  
Fax-on Demand: (703) 787-3441  
BBS: (703) 787-3444  
Website: <http://www.eurotherm.com>  
Technical Library: [www.eurotherm.com/library.htm](http://www.eurotherm.com/library.htm)  
Email: [sales@controls.eurotherm.com](mailto:sales@controls.eurotherm.com)  
[support@controls.eurotherm.com](mailto:support@controls.eurotherm.com)

### Europe:

EUROTHERM CONTROLS LTD

Eurotherm Controls LTD  
Faraday Close  
Durrington  
Worthing  
West Sussex  
BN13 3PL

Tel: +44-1903-268500  
Fax: +44-1903-265982  
Website: <http://www.eurotherm.co.uk>



## Appendix D

### MOTORISED VALVE CONTROL

The 2216e can be configured for motorised valve control as an alternative to the standard PID control algorithm. This algorithm is designed specifically for positioning motorised valves.

The motorised valve algorithm operates in the *Velocity* mode, which does not require a position feedback potentiometer for control purposes.

The following parameter list will appear in the navigation diagram shown in Chapter 2; if your controller is configured for motorised valve control.

Name	Description	Values		
		Min	Max	Default
$\Delta P$	<b>Output list</b>			
$mtr$	Valve travel time in seconds. This is the time taken for the valve to travel from its fully closed position to its fully open position.	0.0	999.9	30.0
$OPLo$	$OPLo$ is the low output power limit.	- 100.0	100.0	- 100.0
$OPHi$	$OPHi$ is the High output power limit	- 100.0	100.0	100.0
$OnT$	Output pulse minimum on time, in seconds.	Auto	999.9	0.2

**Table D-1 Motorised valve parameter list**

### COMMISSIONING THE MOTORISED VALVE CONTROLLER

Proceed as follows:

1. Measure the time taken for the valve to be raised from its fully closed to its fully open position and enter this as the value in seconds into the ' $mtr$ ' parameter.
2. Set all the other parameters to the default values shown in Table D-1.

The controller can then be tuned using the automatic or manual tuning techniques.

#### ADJUSTING THE MINIMUM ON-TIME ' $OnT$ '

The default value of 0.2 seconds is satisfactory for most processes. The minimum on time determines how accurately the valve can be positioned. The shorter the time, the more precise the control. However, if the time is set too short, process noise will cause an excessively busy valve.



## MOTORISED VALVE APPLICATIONS

### AUTO TUNING

Before the auto tune is activated, the  $t_d$  parameter must be set to a numeric value. The  $t_d$  parameter cannot be set to  $OFF$  when an auto tune is activated. When the auto tune is complete, the auto tune will set the  $t_d$  parameter back to the  $OFF$  position.

### 2200e Valve Positioner Set-up Table

Name	Description	Value
$CONF$	<b>Configuration Mode</b>	
$Ctrl$	In the $Inst$ configuration list set the $Ctrl$ to $uP$ .	$uP$
$1A$	Module 1A $id$ needs to be a $RELY$ or a $SSr$ . The $Func$ for 1A should be configured for $HEAT$ . (Open Valve)	$HEAT$
$2A$	Module 2A $id$ needs to be a $RELY$ or a $SSr$ . The $Func$ for 2A should be configured for $COOL$ . (Close Valve)	$COOL$
$OPER$	<b>Operating Mode (OP List)</b>	
$mt_r$	Valve travel time in seconds. This is the time taken for the valve to travel from its fully closed position to its fully open position.	$30.0$
$OP.Lo$	Low output power limit.	$-100.0$
$OP.Hi$	High output power limit	$100.0$
$On.t.H$	Output pulse minimum on-time, in seconds.	$0.2$
$OPER$	<b>Home List</b>	
$UPDS$	Calculated position of valve	% of motor travel time

Table D-2 Valve Positioner Set-up Table

#### NOTE



The following operating parameters do not effect the 2200e when the valve positioner option has been configured:

$CHC.H$  Heat Cycle Time

$CHC.C$  Cool Cycle Time

$on.t.C$  Minimum on time for cooling



## Appendix E LOAD CURRENT MONITORING AND DIAGNOSTICS

Current flowing in a system of electrical heating elements (the 'Load') can be displayed on the controller by using a Eurotherm TE10 SSR fitted with intelligent current transformer, PDCTX, or an SSR or contactor with an external PDCTX.

Load current monitoring and diagnostics may be used with any time proportioned output, fitted in module position 1A, and uses the logic output wires which drive the SSR to return signals back to the controller. These signals represent the RMS value of the load current during the ON period, or load related alarm conditions. It is not designed for analogue outputs i.e. phase angle control.

It is also designed for single phase operation only.

There are two modes of operation:-

### 1. Mode 1

Detects if there is a **break in the heater circuit**. This includes heater or SSR open circuit. A single **Load Failure** alarm message is displayed on the lower readout of the controller.

### 2. Mode 2

Provides the following:-

<b>Display of true RMS load current</b> On the lower readout of the controller	Displays the true RMS current in the ON state to the load.
<b>Low current alarm</b> Analogous to Partial Load Failure (PLF) supplied in some Eurotherm SSRs	Provides advanced warning of failure of one or more heaters in parallel
<b>High current alarm</b> Activated when the heater exceeds a set limit	Typically used where element bunching may occur
<b>SSR short circuit</b>	This will apply full power to the heaters which could result in an over temperature condition. This alarm provides early warning.
<b>Heater failure</b>	Indicates open circuit load conditions




**EXAMPLE WIRING DIAGRAM (FOR MODE 1 & 2 OPERATION)**

**Hardware Required**

1. Eurotherm SSR type **TE10/PDS2** OR
2. Eurotherm intelligent current transformer type **PD/CTX** + **contactor or zero voltage switching SSR**

2216e controller configured for PDSIO mode 2 option using logic output. This module must be fitted in module position 1. (order code **M2**).



**Figure E.1 Connections for Mode 1 & 2**



**WARNING!**

Take care that the controller is correctly wired for the mode of operation which is configured. Failure to do so may be hazardous in some situations.



**OPERATION**

**To Read Load Current (mode 2 only)**

Do This	This Is The Display You Should See	Additional Notes
<p>From the 'HOME' display, Figure 1.4,</p> <p>Press  until <i>AmPS</i> is shown in the upper display</p>	<div style="display: flex; flex-direction: column; align-items: center;">  <p style="margin: 5px 0;">Current will be displayed in the lower readout. See also 'Display Modes' below.</p>  <p style="margin: 5px 0;">This display will be shown if:</p> <ol style="list-style-type: none"> <li>I. The controller is unable to resolve the reading</li> <li>II. The controller is obtaining a reading</li> <li>III. The measurement has timed out i.e. current has not flowed for 15 seconds.</li> </ol> </div>	<p>It will revert to the HOME display after 45 seconds or 10 seconds if an alarm is present</p>

**To Display Load Current Continuously in the Lower Readout (mode 2 only)**

Do This	This Is The Display You Should See	Additional Notes
<p>From the 'HOME' display, Figure 1.4,</p> <p>Press  until <i>d, SP</i> is shown in the upper display</p> <p>Press  or  until <i>AmPS</i> is displayed in the lower display</p>	<div style="display: flex; flex-direction: column; align-items: center;">  </div>	<p>Current will be displayed in the lower readout continuously when the controller reverts to the HOME display, see also 'Display Modes' below.</p>

**Display Modes**

**SSR RMS On State Current**

This is the default state when high or low current alarms are configured. The load current displayed is the steady state true rms current measured during the ON period.

The minimum on time is:-

Mode 2                    0.1second



## How Heater Alarms Are Displayed


Do This	This Is The Display You Should See	Additional Notes
If an alarm is present it will flash a four character mnemonic in the lower display	<p>Actual Temperature (PV) →</p>  <p>The image shows a digital display labeled 'HOME Display'. At the top, there are two small boxes labeled 'OP1' and 'OP2'. The main display area shows the number '20.0' in a large font, with 'LCr' in a smaller font below it. At the bottom of the display, there are four buttons: a square button with a document icon, a circular button with a refresh icon, a triangular button pointing up, and a triangular button pointing down.</p>	If more than one alarm is active, the display will alternate between the alarm messages and the default parameter in the lower display

### The Alarm Messages are:-

Mnemonic	Meaning	Description
The following two messages are alarms which are produced as a result of failure within the process. In place of dashes the alarm number will appear i.e 1, 2, 3, or 4		
-LCr	Alarm number - <u>L</u> ow <u>C</u> urrent	Used for partial load failure detection. To avoid nuisance tripping due to supply voltage variations set to a value at least 15% below the minimum normal operating current
-HCr	Alarm number - <u>H</u> igh <u>C</u> urrent	Used for load overcurrent protection. To avoid nuisance tripping due to supply voltage variations set to a value at least 15% above the maximum normal operating current. <b>Note: This alarm is not intended to provide instantaneous safety protection from short circuit fault conditions</b>
The following message is a diagnostic alarm which appears for mode 1 operation only.		
LdF	<u>L</u> oad <u>F</u> ail	This includes failure of the heater circuit or the SSR
The following two messages are diagnostic alarms produced as a result of failure within the equipment or wiring connections. They appear for mode 2 operation only.		
HtF	<u>H</u> eater <u>F</u> ail	No current is being drawn while the controller output demand signal is on
SSrF	<u>S</u> SR <u>F</u> ail	The load is continuously on while the controller output demand signal is off



### TO SET THE ALARM TRIP LEVELS

Do This	This Is The Display You Should See	Additional Notes
<p>From the HOME display</p> <p>press  until the <b>AL L, SE</b> is displayed</p>		<p>To select the Alarm List header</p>
<p>Press  button</p> <p>until the desired alarm number is displayed</p> <p>Press  or  to adjust the alarm trip level</p>		<p>To select the diagnostic alarm parameter found under the Alarm List header</p> <p>The alarm trip level is set to 123</p>

### RELAY OUTPUTS

Any plug in module can be used for alarms provided they are not already being used for another purpose, such as control. Any one or more alarms can be attached to an output, which will operate when an alarm occurs. Contacts are rated at 2A 264Vac for operating external beacons or audible devices.






## TO CONFIGURE PDS LOAD CURRENT DIAGNOSTICS

Configuration of PDS load current diagnostics is in four parts:-

1. Configure the Logic Module for PDSIO Mode 1 or 2 operation..
2. Configure the Low and High Current trip alarms.
3. Attach the alarms to operate an output relay.
4. Set up the Scaling Factor.

**First enter Configuration Level.** See Chapter 5

### TO CONFIGURE THE LOGIC MODULE FOR PDSIO MODES 1 OR 2

Do This	This Is The Display You Should See	Additional Notes
Press  until the <i>1A Conf</i> is displayed		This opens the configuration list associated with module position 1A
Press  to show <i>id</i>		This shows the identity of the module The module identity is <u>logic</u> output
Press  to show <i>Func</i> Press  or  to show <i>SSr 1</i> or <i>SSr 2</i> as required.		This shows the <u>function</u> of module The module function is set to PDSIO mode 1
Press  to show <i>SEnS</i> Press  or  to show <i>nor</i>		This sets the output signal to normal for heating control



### TO CONFIGURE LOW AND HIGH CURRENT TRIP ALARMS

Alarm 1 will be configured as Load Current Low (LCr)

Alarm 2 will be configured as Load Current High (HCr)


Do This	This Is The Display You Should See	Additional Notes
Press  button until the <i>AL Conf</i> is displayed		This opens the configuration list which contains the Alarms
Press  to show <i>AL 1</i> (alarm 1)  Press  or  to show <i>LCr</i>	 <p>After 0.5 sec the display will blink to show the alarm type has been accepted</p>	To select alarm 1  To make alarm 1 = <u>L</u> ow <u>C</u> urrent
Press  until <i>AL 2</i> (alarm 2) appears  Press  or  to show <i>HCr</i>	 <p>After 0.5 sec the display will blink to show the alarm type has been accepted</p>	To select alarm 2.  To make alarm 2 = <u>H</u> igh <u>C</u> urrent


**Note:** The above alarms are known as **SOFT ALARMS** because they are indication only.



### TO ATTACH SOFT ALARMS TO A RELAY OUTPUT

Any one alarm indicated above may be attached to an output (normally a relay).  
 Alternatively any combination of alarms may be attached to operate a relay using the procedure below:-

Do This	This Is The Display You Should See	Additional Notes
Press "PAGE" key  as many times as necessary to <b>3A</b> Conf		Any output module can be configured for an alarm output provided it is not used for any other purpose, eg as a control output. In place of <b>3A</b> you should select the module required, i.e. <b>1A</b> or <b>2A</b>
Press  until <b>d1 GF</b> appears		<b>d1 GF</b> = digital functions <b>no ch</b> = no change
Press  or  until the first alarm you wish to attach to the 3A output is displayed e.g. <b>Ht r F</b>  Repeat the above step for every alarm to be attached to the output		After 0.5 second the display will revert to <b>no ch</b> to attach the alarm  Each time you scroll through the table of alarms note that two decimal points appear. This confirms that the particular alarm has been attached to the output, i.e. <b>Ht r F</b> <b>Ss r F</b> etc



To remove alarms from an output press  or  until **CLr** appears in the lower display. This will clear all alarms attached to this output.



## THE SCALING FACTOR

The value of the current displayed on the controller is scaled using the scaling factor. This is found in the `Inst Conf` list. It is set, by default, to 100 and assumes a single turn through the current transformer. If two turns are made through the current transformer it will be necessary to adjust the scaling factor to 50 to obtain the same reading.

Under normal conditions you should not need to change the scaling factor.

If, however, you wish to change the sensitivity of the current reading, for example, to read very low currents you may need to change the number of turns through the PDCTX and/or adjust the scaling factor to compensate. See also note 1 below.

## TO ADJUST THE SCALING FACTOR

Do This	This Is The Display You Should See	Additional Notes
Press  button until <code>Inst Conf</code> is displayed		
Press  until <code>LCH<sub>1</sub></code> is displayed		
Press  or  to change the scaling factor		

### Note 1:-

#### Minimum Resolvable Current

TE10 4A RMS. It is not possible to read currents lower than 4A when using a TE10.

PDCTX 4A RMS for a single turn through the PDCTX

Should you wish to read currents lower than 4A using a PDCTX it is necessary to increase the number of turns through the PDCTX and adjust the scaling factor to compensate.

For example: To read 1.0A wind 4 turns through the PDCTX and adjust the scaling factor to 25 as shown in the table below.

Scalar = 100/N Where N = Turns through PDCTX	
N	Scalar
1	100
2	50
4	25
5	20
10	10



**Maximum Resolvable Current**

TE10 Determined by the maximum range of the SSR

PDCTX 100A (or 100 ampere turns)

**Finally Exit configuration level.** See Chapter 5.

## Appendix F RETRANSMISSION

### WHAT IS RETRANSMISSION

The controller can be configured to generate an analogue output signal which represents a selected parameter.

The parameters which can be configured for retransmission are:-

1. Process Variable
2. Setpoint
3. Error
4. Control Output

The retransmission signal is available as 0-20mA, 4-20mA, 0-5V, 1-5V or 0-10V and is connected to terminals 1A and 1B when module 1A is fitted as a DC module.



## TO CONFIGURE THE CONTROLLER FOR RETRANSMISSION

A DC module must be fitted in module position 1A.

**First enter configuration level.** See Chapter 5.

Then:-

Do This	This Is The Display You Should See	Additional Notes
Press  button until the <i>1A CONF</i> is displayed		This opens the configuration list for module 1A.
Press  to show <i>1d</i>		<p>This is the identity of the module fitted in this position</p> <p>The module must be a DC output <i>dCOP</i></p>
<p>Press  to show <i>Func</i></p> <p>Press  or  to select the parameter for retransmission</p>	<p>The choices are:-</p> <p><i>nonE</i></p> <p><b>Control Outputs</b></p> <p><i>HEAT</i></p> <p><i>COOL</i></p> <p><b>Retransmission</b></p> <p><i>OP</i></p> <p><i>PU</i></p> <p><i>Err</i></p> <p><i>wSP</i></p>	<p>Output turned off</p> <p>Heat control output</p> <p>Cool control output</p> <p>Output demand</p> <p>Process Variable</p> <p>Error</p> <p>Setpoint (working)</p>
Press  to show <i>SEnS</i>		If <i>Func</i> is a retransmission parameter the value of <i>SEnS</i> has no effect.



Press  to show  
OUTL



The retransmitted output signal can be limited by adjusting these parameters.

Press  to show  
OUTH




To reverse the output, set OUTL to 20.0 and OUTH to 0.0.

### SCALING RETRANSMITTED OUTPUT SIGNALS

The analogue output signal may be set between 0 and 20mA. A 4-20mA output is achieved by applying an offset as described below.

A 0 to 10Vdc output may be achieved by fitting a 500 ohm resistor across the output terminals 1A and 1B. A 0 to 5Vdc output may be achieved by fitting a 250 ohm resistor across the output terminals 1A and 1B. Suitable resistors are supplied with the controller.

#### To Range Retransmitted Output




For output of 0-100% = 0-20mA  
set OUTH to 20.0 and OUTL to 0.0

For output of 0-100% = 4-20mA  
set OUTH to 20.0 and OUTL to 4.0



### To Range Retransmitted Setpoint $SP$ or Process Variable $PU$



For output of 0 - 1000°C = 0-20mA

set  $outL$  to 0.0 and  $outH$  to 20.0


and  $rnL$  to 0.0 and  $rnh$  to 1000

$rnL$  is the low limit of the input range

$rnh$  is the high limit of the input range

These are found in the  $P$   $CONF$  list as described in Chapter 5. If the range limits are not set the retransmitted output is the maximum input range as stated in the order code, Appendix A.

### To Range Retransmitted Error $Err$



The retransmitted output value is dependent upon the range limits  $rnh$  and  $rnL$  set in the  $P$   $CONF$  list of the controller.

The following examples are given to illustrate the retransmitted error values:

#### Example 1:

Type K thermocouple,

$rnL = -200$

$rnh = +200$

Retransmitted Value

0mA for an error of -200

10mA for an error of 0

20mA for an error of +200

#### Example 2:

As above but  $rnL = -10$  and  $rnh = 400$

Retransmitted Value

0mA for an error of -10

0.0487mA for an error of 0

20mA for an error of +400

#### Note:

To read a negative error it is necessary to set  $rnL$  to a negative limit

